

# Download communication package by WireShark

D027\_v1.0





# Preparing

Download software - WireShark:

<https://www.wireshark.org/download.html>

Please prepare

- Trox 20
- Allen screwdriver
- Internet cable

# Step 1: Open right side cover




- ❑ Turn off the power by key switch at left side of DC wallbox or upstream breaker.

Remove filter cover with T20 torx driver


- Release the two screws on top.
- Release the two screws on bottom and pull out the latch.
- Open and remove the filter cover.



Remove protection cover



## Step 2: Connect cable




- Using CCS CSU (right one)
  - Connect internet cable to CCS CSU (point 1)
- 
- ❑ Turn on the power by key switch at left side of DC wallbox or upstream breaker.

# Step 3: Preparing software

1. Open Wireshark



2. Select "Regional connection" (or "區域連線")



3. Start charging







# Step 4: Capture wireshark data

4. During charging, check "homeplugAV" in protocol field represent it's charging.

No.	Time	Source	Destination	Protocol
4	12.645238000	DeltaE1e_06:9e:cc	Broadcast	HomePlug AV
5	12.653902000	DeltaE1e_07:90:22	DeltaE1e_06:9e:cc	HomePlug AV
6	12.736676000	DeltaE1e_06:9e:cc	Broadcast	HomePlug AV
7	12.771594000	DeltaE1e_06:9e:cc	Broadcast	HomePlug AV
8	12.796596000	DeltaE1e_06:9e:cc	Broadcast	HomePlug AV
9	12.803349000	DeltaE1e_06:9e:cc	Broadcast	HomePlug AV

5. Press "stop" button when charging complete



6. Save file and send to Delta service team

# Smarter. Greener. Together.

To learn more about Delta, please visit [www.deltaww.com](http://www.deltaww.com).

