
DC Wallbox_Alarm 00400D Check Inlet Air Thermal Sensor

Nov. 14, 2019 D018_v1.0









- 1. Remove the fan guard.
- 2. Push in the fan to pull out the two wires of the thermal sensor. Measure the resistance across the two wires at the locations of the yellow tubes through the tiny tips of the multimeter. You may need to use tiny tips to access to the metal parts inside the yellow tubes.
- 3. The resistance is about 5.8kOhms at 25 degree C.

Smarter. Greener. Together.



To learn more about Delta, please visit www.deltaww.com.