

# Replace the auxiliary power

DS05\_v1.0





# Relevance part number

- DCM-121A A-S



## **WARNING!**

To avoid danger of electrical shock or injury, turn off power at the panel board or load center before working on the equipment or removing any component. Do not remove circuit protective devices or any other component until the power is turned off.

Disconnect electrical power to the DC Wallbox before any maintenance work to ensure that it is separated from the supply of AC mains. Failure to do so may cause physical injury or damage to the electrical system and charging unit.

# Remove left side cover



## Remove filter cover with T20 torx driver

- Release the two screws on top.
- Release the two screws on bottom and pull out the latch.
- Open and remove the filter cover.

# Remove protection cover

- Remove protection cover



# Replace the auxiliary power

Step1:



➤ Use screw driver to loose the screw

Step2:



➤ Pull up the auxiliary power then replace it.

# Smarter. Greener. Together.

To learn more about Delta, please visit [www.deltaww.com](http://www.deltaww.com).

